



The Nova

Remote Control Programming Guide

NHTC Remote Programming Guide

There are currently 3 types of Set-Top Boxes (STB's) that will work with the Nova remote control.



ADB 1721W



5721WNX /w Hard drive



3721WN

ADB 1721W Setup

The Nova remote will come already programmed to work the 1721W Set Top Box.

To set up the Nova Remote to work with the 1721W Follow the instructions below.

1. Press the **STB** key on the Remote
2. Press and hold the **SETUP** key and the yellow '**A**' simultaneously until the STB button blinks twice.

ADB 3721 & 5721 Setup

To set up the Nova Remote to work with the 3721 and 5721 follow the instructions below.

1. Press the **STB** key on the Remote
2. Press and hold the **SETUP** key and the red '**C**' simultaneously until the STB button blinks twice.

To program your Nova remote to your Television follow these simple steps.

1. Press and hold the **SETUP** until the **LED** light Blinks Twice
2. Press the **TV** key
3. Press and Hold the **OK** key
4. Let Go of the key when your device turns off

Please note that these instructions are also printed on the back of your Nova remote.