



New Hope  
VISION



The Potenza  
Remote

## Remote Control Programming Guide

# NHTC Remote Programming Guide

There are currently 2 types of Set-Top Boxes (STB's) that will work with the Potenza remote control.

5721WNX w/ hard drive



## #1 START WITH TV TURNED ON

### Code Search Method

Press and release the TV button. The next four steps need to be done in quick succession.

1. Enter in 9-9-1
2. Aim the remote at the TV and press and release the POWER button.
3. Press and release the CH+ or CH- until the TV shuts off. When you are doing the CH+ or CH-, you must do it slow enough to react when your TV shuts off.
4. Press the POWER button to turn the TV on.
5. Press the RCU SETUP button to store the code for the TV. The TV button will blink twice. The remote is now ready to operate the TV.

## #2 LEARNING METHOD

This means that you can transfer the information from the FACTORY ISSUED remote to the ADB remote. (power, volume, etc.) It bypasses having to do the code search method.

1. Press the RCU SETUP until the last selected mode button blinks twice. (TV,DVD, etc.)
2. Enter in 9-7-5 and press the TV button
3. Press the button you wish to program (i.e. POWER) on the ADB remote
4. Place the ADB remote and the ORIGINAL remote head-to-head about 2 inches apart.
5. Press and hold the SAME button (POWER) on the ORIGINAL remote. The ADB remote TV button will blink rapidly and turn off. Keep holding the button on the ORIGINAL remote until the TV button on the ADB remote blinks twice.

If the learning failed, the TV button will emit one long blink. Repeat final step.

3721WN

